



1 APPARATUS AND METHOD TO PREPARE IN-SITU PILINGS
2 WITH PRE-SELECTED PHYSICAL PROPERTIES

3 Specification

4 Field of the Invention

5 For preparing in-situ pilings, apparatus and method to
6 assure the concurrent presence of water and binder at known
7 depths to cure to pre-selected physical properties.

8 Background of the Invention

9 Structures such as roadways, railways, embankments, and
10 levees must often be built on soil structures which are
11 insufficiently strong to support their intended loads,
12 immediately or after a considerable passage of time. Yet
13 physical constraints require that these projects be built there.
14 For example, a road must skirt a hill, pass through a meadow, or
15 pass through a soggy a plain next to it. The alternative would
16 be an unaffordable tunnel. Or perhaps a levee must be built next
17 to a river to protect a city. The alternative of moving a city
18 such as New Orleans itself so as to locate a levee at a more
19 convenient location is not even to be considered.

20 Accordingly, means have been sought to strengthen existing
21 soil structure so that when it is modified it will be able
22 vertically to support or laterally to resist design loads that
23 the existing soil could not have supported. One well-known
24 technique is to mix cement or lime (or both) into the soil so as

2987638270U 15 Feb 07
"Express Mail" mail label Date of Deposit
I hereby certify that this paper or fee is being deposited with the United States Postal Service "Express Mail" Post Office to
Addressed Service under 37 CFR 1.10 on the date indicated above and is addressed to the Commissioner for Patents, P. O. Box 1450,
Alexandria, VA 22303-1450
Donald B. Koss Reg. No. 10,255

1 to make a stronger subsurface structure. Perhaps the best known,
2 or at least the most frequently-encountered, example is to add a
3 reinforcing binder such as cement and/or lime into the existing
4 soil in a vertical bore so that when the resulting mixture cures,
5 it forms an in-situ piling. This piling is thereby constructed
6 of the existing soil as an aggregate plus the added binder. Of
7 course, the ultimate strength of the piling can be attained only
8 if water already exists along with the aggregate, or is supplied
9 when the piling is formed. The ultimate objective is to make a
10 cementitious stoichiometric mix of water and binder that will in
11 time harden to its best properties.

12 In addition, the strength properties of the piling depend
13 strongly on the amount of binder supplied to it. A
14 stoichiometric mixture merely requires sufficient water to cure
15 the amount of binder that is supplied.

16 An example of in-situ piling is shown and described in
17 applicant's United States patent No. 5,967,700 issued October 19,
18 1999. It is the sense of this patent to know the need for water
19 at various elevations in the intended structure, and to mix it in
20 with the existing soil on the way down into the soil, and then on
21 the way up, to mix in the necessary amount of cement or lime to
22 form a piling of desired characteristics.

23 Such pilings, and also those made with the present
24 invention, should not be confused with conventional pilings that

1 are prepared off-site. Conventional pilings brought to the site
2 are then and there driven into the soil. These are sometimes
3 lengths of timber. Other times they are poured and cured
4 concrete structures, all with very substantial compressive,
5 shear, and fracture strength. They do not integrate themselves
6 in the soil structure into which they are driven, nor do they
7 include any part of the existing soil in themselves. Instead
8 they exist as free-standing foreign bodies. They are costly to
9 manufacture, transport to the site, and drive into the ground.
10 Their cost, and to a surprising extent, their excessive physical
11 properties lead engineers to use them sparingly. For piers,
12 building foundations, and the like, their use is economically
13 justified. However, to provide many of them per mile for many
14 miles of a roadway or levee can rarely be justified. Also, their
15 inherent strength is much greater than needed for purposes of
16 this invention.

17 The preparation of an in-situ piling is inherently less
18 costly than the use of a piling prepared off-site. It requires
19 only an auger/mixer to drill into the soil structure and inject
20 and mix materials which, along with whatever soil is already
21 present, will hopefully cure to a solid in-situ vertical piling
22 which has stronger properties than the surrounding soil.
23 Furthermore, its boundaries with surrounding soil structure will
24 not be as abrupt as those of a driven piling. Instead, when

1 properly made, the boundary is likely to be a gradual transition.
2 These are fundamental considerations when one decides to provide
3 an in-situ piling, and how to make it.

4 The genuinely surprising fact exists that in practice in-
5 situ pilings have not been built to their anticipated strength
6 levels, even when these levels were known, which is not
7 necessarily a uniform property throughout the depth. In fact
8 this shortcoming has not been widely noticed, nor in most
9 practice has it been recognized as a problem. Generally the
10 concept has been to put a calculated amount of a binder in the
11 bore, mix it into the soil, and leave.

12 The necessary properties of an in-situ piling are
13 surprisingly less than those of a driven piling, only in part
14 because they do not have to withstand driven forces. Prominent
15 among reasons for this is because they usually have a very much
16 larger cross-section. It is not unusual for an in-situ piling
17 to have a diameter as great as 36 inches, while a driven piling
18 usually will be no larger than 18 inches in diameter, in large
19 part because of the substantial skin friction that must be
20 overcome to sink a piling. In-situ pilings do not face this
21 problem. There is no skin friction to resist driving forces.

22 Also, because of their lower and affordable cost, there can
23 be many more of them.

24 Compressive strengths as low as 40 psi are considered to be

1 acceptable for many in-situ pilings, which may be as deep as 60
2 feet. Interestingly, these may be prepared in as short a time as
3 5 minutes. Thereafter they cure in times calculated in hours or
4 days. Driven pilings are simply unable to compete with such a
5 pace.

6 There are two basic generally-used methods to form in-situ
7 pilings: the wet and the dry. The wet method injects a slurry of
8 water, cement and/or lime into the bore as the auger either
9 enters or leaves the bore, or at both times. The auger itself
10 rotates vanes which both drill into the soil and mix the soil and
11 injected slurry. The slurry is prepared in a mixing plant
12 located on the surface. It is fed under pressure to the auger
13 through pipes and hoses. The slurry is forced under pressure
14 from the auger into the soil. It enters the soil as a strong
15 stream. If the soil is dry, then a slurry injected and mixed
16 into it would appear to be an ideal arrangement.

17 However, there are several serious disadvantages to this
18 arrangement. The slurry in the lines, if permitted to stand too
19 long such as during an interrupted operation for a substantial
20 time, or overnight, will harden in the system. Then the system
21 itself must be taken apart and cleaned out, or parts must be
22 replaced as necessary. Also, unused slurry must be disposed of
23 at the end of a work shift. This becomes an ecological problem.
24 These are disadvantages at the surface and in the equipment.

1 They do have the advantage that they can be "fixed", but at a
2 substantial cost.

3 The subsurface problems with the wet method are more severe.
4 They are even more worrisome because they can and often do result
5 in a deficient piling. Slurry to be pumpable and mixable in the
6 soil must have some known amount of water of its own. If the
7 amount of water in the slurry plus water in the formation is
8 sufficient for hydration of the amount of cement and lime, then
9 an in-situ piling formed with it in dry soil could be proper.
10 The usual situation is that most soil (but far from all) has
11 useful water in it, although not at all depths, and it can occur
12 at different wetness at various depths.

13 Accordingly, a slurry of constant properties and composition
14 can end up either not diluted or diluted to an unknown or
15 excessive extent, unless it was precisely constituted for the
16 immediate depth in the formation, which cannot effectively be
17 done with mixing equipment at the surface which must be a
18 continuous operation with long hose lines filled with already
19 mixed slurry. In designing an in-situ piling using the wet
20 method, the engineer must either accept a minimal load value or
21 an over-design. Then he must over-pay for a larger piling, or
22 for more pilings, or for extra binder, all of which can be
23 prohibitively costly. These are serious disadvantages in days
24 when money is short. Design criteria in excess of real

1 requirements can not be tolerated, but is, in the absence of an
2 alternative.

3 The dry method has even more severe restraints and
4 consequences. In this method, dry cement and/or lime is mixed
5 into the bore through the auger while the auger drives into the
6 soil and stirs it. Existing water is relied on for the curing.
7 Sometimes water is injected into the soil, but attention is
8 rarely given to the variability of wetness at various depths. As
9 a consequence, examinations of many completed in-situ pilings
10 show various properties at different depths, extending from
11 almost negligible strength near the surface where it is likelier
12 to be drier, to excessive water potentially leading to reduced
13 strength at depths where there was a deleterious excess of water
14 when the piling was formed.

15 Applicant has developed a third method, with which he
16 assures that at all pertinent depths there will be sufficient
17 water to react with the binder he supplies, and also that there
18 will be a proper amount of binder at each depth. The amounts of
19 binder and of water supplied by this third method can and often
20 will vary for depth to depth.

21 The objective is to produce at each depth a column having
22 strength and dimensions suitable for each respective depth.

23 While so doing, energy loads on the equipment are
24 significantly reduced. This is especially the situation when the

1 soil is dry. Rotating and driving an auger in dry soil requires
2 a substantial effort. The introduction of the water provides
3 lubricity which reduces the energy load to drive the auger.

4 A further disadvantage of the prior art is the method of
5 injecting the binder. It is customarily injected into the bore
6 by a compressed air stream. The problem here is the distribution
7 of the binder when it arrives in-situ. To obtain the best piling
8 the binder should be evenly distributed, but pneumatic propulsion
9 of a dry powder into a variable region often results in uneven
10 distribution because of the nature of the formation into which it
11 is injected. It may shoot all the way to the edge of the bore,
12 or may be stopped quickly and never go very far into it. It then
13 is the task of the auger to correct this by proper stirring of
14 the entire mixture.

15 Applicant has found that the preparation of in-situ pilings
16 with consistent and known properties depends heavily on the
17 distribution of the water and binder in the bore, on the accurate
18 and known presence and supply of each, and the nature of the soil
19 in which the piling is formed. It must be kept in mind that
20 while this process is relatively rapid, it still takes some time.
21 For example, a 60 foot deep piling completed in five minutes
22 requires axial auger movement at the rate of about 24 feet per
23 minute. The usual rate of rotation of the auger is between about
24 150-250 rpm. Thus the auger travels axially at between about 15

1 and 30 mm per revolution. Accordingly, the binder is injected at
2 a fairly rapid rate. However, its distribution and the water
3 content of the soil at the point of injection is dependent on the
4 nature of the soil- it is more difficult to penetrate clay than
5 sand or sandy soil, for example, while in sandy soil water may
6 drain quickly. Therefore, especially when fast-setting binders
7 are used, there is the risk of earlier agglomeration of binder
8 and water, and for slower-setting binders of a lesser amount of
9 water because some water may have drained away. The injection of
10 dry binder can vary also with the existing water content of the
11 soil.

12 As to the addition of water, it is observed that the most
13 troublesome situation occurs in sand or very sandy soil, from
14 which existing and especially added water may drain away in
15 important amounts before it is contacted by the binder. Thus, it
16 is not only important to assure the presence of known amounts of
17 water at various levels, but to have them there when the binder
18 is added.

19 It is an object of this invention to provide process and
20 equipment to enable local control over the injection of water and
21 binder, and in such a way that the water and binder are in place
22 in correct amounts at the time and place where they are to cure,
23 and to mix them there. This invention provides the advantages of
24 the wet method, but creating a slurry locally without the

1 disadvantages of the wet method.

2 Brief Description of the Invention

3 The method of the invention comprehends adding, at least at
4 some levels in the bore of an intended in-situ piling, water and
5 binder in amounts sufficient along with existing water that when
6 cured to create with the existing soil used as aggregate, an in-
7 situ piling of desired strength characteristics will result. It
8 is intended that after the auger has passed both up and down,
9 there will remain a well-mixed mixture which when cured will from
10 top to bottom fulfill the intended structural requirements at all
11 depths.

12 According to this invention, water and binder, both as
13 required at the various depths, are supplied separately, under
14 separate controls, to functionally nearby injectors. Each
15 injector is separately controlled to deliver on demand water or
16 binder, respectively, and in a direction and location whereby the
17 water and binder will meet timely after exiting the respective
18 injectors. Accordingly, there is a timely meeting of these
19 ingredients, well before water could drain away, and well before
20 dry binder could blow through an otherwise too-dry formation.
21 Instead there results, nearby to known locations on the tool,
22 timely close to the moment of separate injection of the water and
23 binder, a properly proportioned supply of water and binder
24 respective to conditions as they exist at the very depth in the

1 bore.

2 According to a preferred but optional feature of this
3 invention, the functionally related injectors are so disposed and
4 arranged such that their emissions (the injected water and
5 binder) meet locally within so short a time that they are in a
6 desired location and become mixed quickly.

7 According to still another preferred but optional feature of
8 the invention the functionally-related injectors are companion
9 injectors whose emissions intersect close to their exits.

10 According to another preferred but optional feature of the
11 invention, a plurality of companion injectors are disposed along
12 an auger vane, so that the initial injection of these ingredients
13 is at a plurality of regions spaced from the central axis of the
14 piling.

15 According to yet another preferred but optional feature of
16 the invention, the rate of supply, and thereby the quantity of
17 supply of water and of binder at respective depths is maintained
18 such as to provide at the respective depth an anticipated desired
19 mix of soil (aggregate), binder and water and if desired, of
20 additives such as sand.

21 The above and other features of this invention will be fully
22 understood from the following detailed description and the
23 accompanying drawings, in which:

24 xxx

1 Brief Description of the Drawings

2 Fig. 1 is a schematic view partly in cross-section showing
3 the use of this apparatus;

4 Fig. 2 is a side view of the vane shown in Fig. 1;

5 Fig. 3 is a fragmentary cross-section taken at line 3-3 in
6 Fig. 2;

7 Fig. 4 is a cross-section taken at line 4-4 in Fig. 3;

8 Fig. 5 is a cross-section showing a modification of the
9 injectors;

10 Fig. 6 is a cross-section taken at line 6-6 in Fig. 2;

11 Fig. 7 is a fragmentary cross-section of part of an optional
12 vane;

13 Fig. 8 is a flow chart illustrating the method of the
14 invention;

15 Fig. 9 is a schematic cross-section explaining the method of
16 this invention; and

17 Fig. 10 is a schematic sketch showing structure for an
18 optional pattern of injection of water and binder.

19 Fig. 11 is a fragmentary side view of a portion of the auger
20 showing a different injection arrangement; and

21 Fig. 12 is an axial half-section taken at line 12-12 in Fig.
22 11.

23 Detailed Description of the Invention

24 This invention is used to reinforce a region 10 in a soil

1 structure 11. Structure 11 may be of any constituency, from sand
2 to sandy to clay, which without reinforcement would not provide
3 sufficient support for an intended usage. Such usages could
4 include vehicular roadbeds, dams and levees as examples.

5 Such soils can vary widely in composition and structural
6 quality. While the gross composition of the soil material at a
7 given depth often will be reasonably consistent over a large
8 area, the water content can and often will vary remarkably from
9 depth to depth, and between adjacent regions. It is not uncommon
10 for a vertical bore to be quite dry for a number of feet in
11 depth, then to become wet, and perhaps dry again.

12 A failing of the existing piling art is that the same amount
13 of cement is often injected at every depth, without regard to the
14 existing water content. Providing binder which is not reacted
15 reasonably promptly provides little ultimate structural
16 advantage. For this reason, many unearthed in-situ pilings are
17 found to be essentially unreinforced because the binder did not
18 cure, or was only locally reacted, which used up all of the
19 available water.

20 Similarly, in very pervious formations, such as very sandy
21 formations, supplied water may have drained away before being
22 useful to the binder for curing purposes.

23 The terms "curing" and "hydration" are used interchangeably
24 in this specification. It means whatever reaction occurs in the

1 hardening of a powdered binder such as cement and/or lime to form
2 from a mixture of water and powder in to a body that acts as a
3 "paste" to bind aggregate together as a solid body. The precise
4 chemical nature of the reaction is not important what is
5 important is the solid result, often spoken of as a cured or
6 hydrated body.

7 The objective of this invention is to produce in soil
8 structure 11 an in-situ piling 12 that extends as a cylinder
9 below the ground surface 13. The piling has a central axis 14,
10 and a dimension of depth 15.

11 While there are many structures in which the soil
12 constituency is constant from the surface, many or most will have
13 different soil or water compositions, especially as to water
14 content at different depths. For example, an upper zone 20 may
15 be quite dry, while lower zone 21 may be wetter, and lower zone
16 22 still wetter. The constituency and wetness of these zones can
17 be learned from cores drawn from borings 24 taken at locations
18 near to one or more places where a piling is to be made.

19 The ultimate strength of a binder-reinforced in-situ piling
20 is a reasonably proportional function of the amount of binder per
21 unit of volume. The designer will sensibly use the minimum
22 amount of binder that will create the desired strength, because
23 the binder is the largest cost. Whatever amount of binder is
24 provided for a given amount of aggregate, and provided that

1 sufficient water is available fully to react that binder, the
2 intended strength will be developed with the use of least binder.

3 The term "stoichiometric" is used herein to denote the
4 presence of sufficient water to result with the binder in a solid
5 and reasonably consistent body. With some cements, completion of
6 the reaction may take a very long time, measured in months. This
7 method may or may not provide all of the water ultimately needed,
8 although it may do so. It will, however, provide sufficient
9 water that the in-situ piling will cure in a reasonable time to a
10 strength consistent with the design criteria. It may or may not
11 strengthen beyond that time, which will usually be measured in
12 days. "Stoichiometric" does not exclude additional water. The
13 precise amount of water needed for hydration, as the only water,
14 is not the exclusive meaning of the term. Additional water
15 merely dilutes the system. Provided that water is not in such a
16 large immediate quantity as to "kill" the binder by preventing it
17 from forming the type of binding matrix intended, excess water
18 content is still within this invention.

19 Also, the term "water" as used herein is intended to
20 comprise water that is available for sufficient hydration (or
21 curing) of the binder of the body. It may be free water existing
22 between particulates of the aggregate, or even loosely bound
23 water more available to the binder than to whatever else it was
24 bound to.

1 The basic equipment required to carry out the process of
2 this invention is a rotary power source 25 on the surface adapted
3 to rotate shaft 26 of an auger 27 around a central axis 28. The
4 power source also has the capacity to thrust the auger axially
5 downwardly into the ground to a selected depth and then to raise
6 the auger to the surface.

7 The auger itself has a head 30 (Fig. 2) with outwardly-
8 extending vanes 31 that meet at the center 32 of the head. These
9 vanes act as a drill during downward movement. They also serve
10 to stir the loosened aggregate.

11 While an auger is often thought of as a drill, progressing
12 through the formation by a given increment for each revolution,
13 this is not a precise definition. A practical auger may have,
14 but often does not have, a sharp leading edge. Instead the
15 leading edge 33 (Fig. 6) is likelier to be rounded, and the
16 trailing bottom surface 34 rather flat. Progress through the
17 soil often involves axial compression beneath the vane so the
18 vane sinks into the soil a bit, and as it rotates this material
19 passes over the top of the vane.

20 While not a precise screw thread pitch, the passage of the
21 auger still is along a generally helical path, although the pitch
22 may vary somewhat along with the length of the bore depending on
23 the composition of the soil. What is important is that as the
24 auger progresses, it generates a volume of loosened soil which it

1 also stirs. It is into this loosened, helically shaped region
2 where at its depth the water content is known, and frequently
3 also the nature of the soil, that binder and water will be added.

4 Usually the rotation of the shaft will be reversed when the
5 head is to be returned to the surface. The vanes will further
6 stir the mixture as they return to the surface.

7 The structure as illustrated is greatly simplified. For
8 example, additional vanes can be added for stirring purposes, and
9 the angle of attack of the vanes can be selected differently for
10 raising and lowering. These considerations are entirely standard
11 in this field.

12 The object of this invention is to be certain that at all
13 depths at least the stoichiometric amount of water is available
14 for the amount of binder injected at various depths, that the
15 correct intended amount of binder is injected, and that the
16 binder and such additional water as may be supplied will be
17 properly distributed and supplied temporally such that the water
18 and the binder are locally in place in the correct amounts at or
19 very quickly after the moment or moments of injection. The
20 binder and the water will be injected in such a way as to be
21 available throughout the structure, and will not be unduly
22 concentrated or agglomerated in localized places.

23 It is also an objective that the system, especially the
24 tool, will not become plugged if the system shuts down abruptly.

1 For those purposes, in the preferred embodiment (Fig. 5),
2 companion injectors 35, 36 are provided in pairs at one or more
3 locations and in numbers of pairs to be described. Injectors 35
4 are to provide binder, and also if desired additives such as
5 sand. Injectors 36 are to provide water. Each injector has a
6 respective discharge axis 37, 38. These axes intersect under in-
7 situ (ambient) pressures adjacent to but spaced from the shaft
8 and where their materials mix, they have a combined component of
9 radial motion. They meet in a limited region 39, which under
10 some circumstances can be regarded as a "premix" region.

11 Water supply 40 at the surface provides water under pressure
12 from a pump 41 to the tool through a conduit 42 that passes down
13 the shaft and out to an injector or injectors. A water control
14 valve 43 (Fig. 8) regulates the flow of water under control of a
15 program 44 which may be manually or computer-controlled as will
16 later be described. This valve determines the rate of flow, and
17 thereby how much water is to be supplied at the current depth of
18 the injectors in the bore.

19 A binder supply at the surface provides binder under
20 pressure from a pressurized supply source 46 to an injector
21 through a conduit 47 that passes down the shaft and out from
22 injector 35. The amount of binder will be under control of a
23 binder control valve 48 (Fig. 8) which can be manually or program
24 controlled. The binder will usually be granular or a powder, so

1 that it can be transported by air pressure. If desired, the
2 binder can be pre-moistened, but this risks clogging of the
3 lines.

4 While the binder will usually be cement, lime, or a mixture
5 of them, of many also include other ingredients such as sand.

6 The intended function and advantage of companion injectors
7 is the very close proximity of the intersection of their
8 discharge axes. When their injected streams meet, preferably
9 within a few inches of their exit from the injectors, wetting and
10 hydration of the binder begins immediately. This provides most
11 of the benefits of a slurry system, but because the supply lines
12 are separate, there will be no clogging if the system stops.
13 Furthermore, because the streams meet, preferably at an acute
14 angle, the resulting mixed stream 41 will have a radial component
15 of velocity such that it is likely to be distributed across the
16 bore. The vane which follows will stir the mixture, even when
17 ahead of the region where the mixture is injected.

18 Speaking generally, in-situ pilings larger than 36 inches in
19 diameter will be rare. More commonly, they will be on the order
20 of about 18 inches in diameter. The central shaft must be
21 capable of driving its vanes to a depth of up to about 60 feet,
22 although shallower pilings will be more common. Even so, the
23 shaft must have sufficient strength to exert the necessary torque
24 and also to press the vane or vanes into the soil while driving

1 it in one direction, and reversing the torque while pulling the
2 tool out of the bore.

3 The shaft will, of course, accommodate the supply lines,
4 which, especially for the dry binder, must have a substantial
5 cross-section. Internal diameters of the shaft will ordinarily
6 be on the order of three inches. The wall thickness of the shaft
7 and its physical properties will be selected to enable the torque
8 and axial loads to be exerted without undue twisting or
9 distortion of the shaft.

10 In such an arrangement, companion injectors will preferably
11 be located within about three inches of one another and their
12 streams will be so directed as to intersect within about three to
13 six inches from their injectors. Their intersecting streams will
14 meet and mix in a limited region such as region 39 so as to
15 produce a mixed stream of binder and water formed of water from
16 the injector. There or shortly beyond it, it will mix with water
17 already present in the bore.

18 The mixture in region 39 can properly be denoted as a
19 "premix", that is, a mixture of binder and added water, which,
20 with the next addition of existing water will result in the
21 desired piling.

22 If the shaft of Fig. 2 is to be used, then as shown in Fig.
23 5, deflectors 42 and 43 will divert their streams toward one
24 another to mix in region 39.

1 Injectors 80 and 81 may be set in the shaft, or they may be
2 set in a vane as shown in Fig. 7. Then their streams, instead of
3 facing outwardly into the bore, will face forwardly into the
4 formation, ahead of the vane. With such an arrangement, the
5 mixed stream can also serve as a better lubricant for the vane as
6 it cuts into the soil.

7 Fig. 7 shows a water injector 80 and a binder injector 81
8 set in the leading edge 82 of a vane 83. As a further advantage,
9 the water injector may be placed and supplied so as to contribute
10 cutting jets to facilitate entry into the soil.

11 Companion injectors (a related pair) may be regarded as a
12 special and preferred example of "functionally-related"
13 injectors. Companion injectors emit their material in such a way
14 that their emissions intersect and promptly mix in-situ.
15 Alternatively, emissions from functionally-related injectors need
16 not directly mix as streams, but instead can be discharged into
17 the soil as separate streams whose injected materials in the soil
18 are placed sufficiently closely in time and dimensions that they
19 can promptly be stirred by the tool in a "temporal" relationship.
20 Such an arrangement can enable the use of a simpler tool.

21 A simple system utilizing functionally-related injectors is
22 shown in Figs. 1-4 in which functional, but not companion
23 injectors are used. This enables the use of the system with only
24 a modification of its drive shaft, does not require modification

1 of the vanes themselves, and does not require immediate
2 intersection of the stream of water and of binder.

3 Drive shaft 51 is a hollow cylinder with a peripheral wall
4 52 and a central passage 53. Vanes (not shown) are driven by the
5 shaft as in Fig. 1. Water supply pipe 42 leads from the water
6 supply to the tool head.

7 Binder supply pipe 47 leads from the binder supply to the
8 tool head.

9 The tool head is coupled to the water and binder supplies by
10 a rotatable coaxial collar (not shown) which provides binder at
11 the center, and water at an annulus. This enables a binder
12 connection to be made to central passage 53, which acts as a
13 binder passage, and water connections to four drilled axial water
14 passages 66, 67, 68, and 69. The number four of these water
15 passages is arbitrary but convenient to provide water injectors
16 at various axial locations.

17 A binder injector 70 (Fig. 2) is drilled through the wall
18 into the binder passage. Preferably its discharge axis 71 is
19 normal to the axis.

20 Water passages 66-69 have respective water injectors 72, 73,
21 74, and 70 which also discharge radially. Selection of which
22 injector or injectors is to be used can be determined by
23 inserting a removable plug 76 in those to be closed. These water
24 injectors are located at selected locations relative to the

1 binder injector. For example, it will be noted that these water
2 injectors can be, and in the drawings some are, pointed in
3 opposite directions from the binder passages. They may or may
4 not be located at the same elevation along the central axis.
5 Thus, the emission streams from these injectors will not directly
6 intersect. However, as will be seen, they inject their streams
7 at such close locations and times that when a "following" stream
8 arrives at some depth, it will soon enough encounter material
9 from a previous stream in a condition and quality ready for
10 complete mixing, for example, before water can drain away, such
11 as through a sandy formation.

12 There is a substantial range of locations of functionally
13 related injectors. Their purpose is not necessarily to provide
14 intersecting streams, but instead to provide their streams in a
15 way such that one of them will, quickly enough, encounter the
16 material emitted from the other.

17 For example, consider that the vanes drive into the soil in
18 a manner similar to a screw thread. It would advance much as a
19 thread, with a "pitch" dimension. That is, the tool would
20 advance an axial distance equal to the pitch for each revolution.
21 This pitch may vary for the same rpm, depending on the
22 characteristics of the soil, but it is a useful analogy.

23 In actual practice, a tool of this type is pressed into the
24 ground rotating at a selected rate between about 150-250 rpm.

1 For convenience assuming the rate is 150 rpm, and the pitch is
2 1.0 inch, it will require about 0.8 seconds for the tool to
3 advance one inch. Now if the first nozzle, whether water or
4 binder, is axially spaced from the next nozzle above it by a
5 distance D, this next nozzle will arrive at the same axial
6 location as the former one in 0.8 seconds times the axial spacing
7 of the two nozzles.

8 Thus, if the nozzles are spaced 10 inches apart and the
9 pitch is one inch, the next nozzle will discharge its contents at
10 the respective point in about 8 seconds. If the spacing D is
11 shorter the time will be shorter. If the rotation is faster, the
12 time will be shorter. If it is slower, it will take longer.

13 These temporal relationships are closely coupled. In most
14 soil structures one can anticipate that a time spacing of less
15 than about 10 seconds between injection of water and binder into
16 the same region will result in the near equivalence to a slurry,
17 and is intended by this invention. Here it will be commented
18 that the same vanes which dig into the soil also will serve to
19 stir it. When the auger is withdrawn it will stir it again.

20 When the streams directly intersect, the mixing is
21 immediate. When they are suitably spaced and directed, the
22 resulting mix will closely resemble a slurry. The forgoing
23 examples are illustrations of a convenient tool, where the
24 streams are radial, perhaps oppositely directed.

1 In a tool as shown, axial spacing of the nozzles of 10
2 inches or less, preferably two or three inches, or even at the
3 same elevation, will usually be used.

4 Fig. 8 illustrates the method of this invention. The
5 amounts of water and the binder to be supplied are tailored to
6 conditions of the soil and to the available water content. This
7 data is known from the test bore, or from measurements made
8 currently with the making of the piling, such as by a sensor on
9 the leading end of the tool.

10 The depth of the tool in the soil formation is known by the
11 operator from direct observation of the tool shaft and from
12 readouts which are respective to tool depth. These are entered
13 into the program, and the water and binder will be supplied by
14 adjusting valves 43 and 48 controlled by the program. Thus, as
15 the tool progresses downwardly (or upwardly) the materials are
16 supplied to create the mix desired at that depth.

17 Fig. 9 schematically illustrates several other features of
18 the invention. Vanes 110 and 111, similar to vanes 31 are driven
19 by a central shaft 111a similar in function to shaft 51.

20 Vanes 110, 111 include respective baffles 112, 113 which are
21 generally aligned with the mutual output emissions 114 of
22 injectors 115. The purpose of these baffles is to keep the
23 emissions within the region of the intended piling. These
24 baffles are preferably located at or near the intended boundary

1 of the piling.

2 The emissions are shown emitting at a height H above the
3 vertex 116 of the vanes. At or near this vertex may be water-
4 content sensor 117. This sensor informs the central system about
5 the available water content of the soil at a depth below height
6 H. Thus, this data 118 can be transmitted to the control system
7 of Fig. 8 to provide the proper amounts of water (or binder) at a
8 depth yet to be treated by the tool.

9 Fig. 10 illustrates an advantage of this arrangement. Here
10 a binder injector 122 is disposed axially between two water
11 injectors 120, 121. With this arrangement, water may be the
12 first-injected material, or instead the binder may be. Generally
13 it will be preferred to inject the water first. In addition,
14 this arrangement enables a selection of order of injection on the
15 way up, or down if additional injection of binder is desired in
16 that direction, or if all binder is to be injected in that
17 direction.

18 It will be observed that the wetness at depth data 119 known
19 from a bore will be used if available, or if not available, then
20 data from the sensor on the tool can be used.

21 Another example of companion nozzles is shown in Figs. 11
22 and 12. In this arrangement outer shaft 150 drives the tool. It
23 has a central axis 151 and a peripheral cylindrical wall 152.

24 An interior coaxial and concentric binder tube 155 has a

1 central passage 152a to deliver binder. A nozzle 156 extends
2 through an opening 157 in the wall of tube 155 and through an
3 opening 157 in wall 152. As best shown in Fig. 12, it delivers
4 binders laterally along an axis 158.

5 A group of water nozzles 159 are formed through wall 152.
6 These nozzles emit water along axes 160. As shown in Fig. 12,
7 axes 160 will intersect axis 158. This is similar to a shower
8 head, in which a central stream is impinged upon by a plurality
9 of other streams. These nozzles may provide a very beneficial
10 effect when the tool is withdrawn from the bore. The water
11 nozzles may be opened to form a spray pattern that will catch any
12 binder dust that may leak from the binder nozzle, preventing a
13 cloud of dust from forming. For this purpose the water nozzles
14 may be turned on, while the binder nozzle is off.

15 Importantly to this invention, the streams intersect within
16 a limited region 161, and from there proceed radially along path
17 162.

18 When streams 158 and 160 intersect, they will carry all of
19 the binder, and such water as is needed to supplement the water
20 already in the formation. Therefore the material in region 161
21 can properly be regarded as a "premix". When added to the water
22 already present in the formation the correct composition for an
23 in-situ piling will have resulted and will be stirred by the
24 tool.

1 This invention thereby provides most of the advantages of a
2 slurry, but without the slurry's serious disadvantages. The
3 water and binder (cement or lime usually, or both) are kept
4 separate until they enter the formation, where they are promptly
5 stirred together in the correct amounts.

6 It should be noted that all addition of water and binder is
7 injected into a region at "ambient" pressure. Ambient pressure
8 is defined as the fluid pressure in the region where the material
9 is injected. Often it is close to atmospheric pressure, but may
10 be somewhat higher depending on local conditions.

11 What is important is that the pressure at the nozzles is
12 higher than ambient, so the material can be injected into the
13 formation. But it also is important because water or binder or
14 their mixture cannot flow backward into the nozzles and into the
15 system. Thus, the system is self-cleaning, and avoids the
16 problem involved in pumping a slurry.

17 Downhole valving can be provided, especially for the water,
18 but for the binder will lend a complexity that is undesirable.
19 Maintenance of super- ambient pressure in the supply lines will
20 guard against back flow. Removal of pressure sufficient to drive
21 the binder or water will prevent back flow and if not excessive,
22 will not drive binder out of the nozzle.

23 Water can be valved directly by the operator, now of
24 desired, appropriate valving can be provided downhole.

1 Sand when used with binder may be regarded as a diluent to
2 and part of the binder.

3 This invention is not to be limited by the embodiments shown
4 in the drawings and described in the description, which are given
5 by way of example and not of limitation, but only in accordance
6 with the scope of the appended claims.